



ASSEMBLY INSTRUCTIONS

ITEM# : GB21-803

SKU# : 810500149

THORNWOOD AW WICKER TWO SEAT SOFA WITH CUSHION

Need help? We are here for you! 1-888-733-8169 Toll Free

Or email us at customerservice_01@yeah.net, customerservice_02@yeah.net

customerservice_03@yeah.net

GENERAL BEST PRACTICE FOR ASSEMBLY:

Read all instructions before starting

Clear a flat covered space to begin assembly

Always best to do it with a friend

Note that hardware required is provided for every step

Pay attention to orientation

Helpful hints provided along the way

Retain these assembly instructions for future reference.

WARNINGS:

Use the correct bolts as indicated. All bolts should be hand tighten until the complete piece is assembled (This will make the assembly process much easier).

Once the piece is fully assembled, then go back and tighten all bolts with provided tool.

Regularly check hardware and tighten if necessary.

Use the correct bolts as indicated. **Do not tighten any of the bolts until the sofa is completely assembled.**

Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.

Keep children and pets away during assembly. This item contains small parts that can be swallowed by children.

Children should always be under direct adult supervision while using this product.

Sofa is for sitting purposes only. Standing on or misuse of sofa may result in damage or injury.

Weight limit is 500 lbs (227.3 kg). Not intended for commercial use.

MAINTENANCE:

Wash frame and fabric parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or fabric parts.

The cushions may be washed on the surface only by using mild soap and water or a commercial foaming upholstery cleaner if necessary.











If washed, rinse well and hang to dry. Do not machine wash or dry.

We recommend the use of furniture covers when not in use.

Inspect and tighten all of the bolts and fasteners on a regular basis to ensure the proper performance and safety of your product.

In order to prolong the life and beauty of your product, we recommend that it be stored in a dry and protected area during off season periods.

PARTS LIST:

Part No.	Part	Qty	Image	Part No.	Part	Qty	Image
1	Sofa Back	1		6	Back Cushion	2	
2	Sofa Seat	1		7	Sofa Foot	4	
3	Right Arm	1		8	Bolt (M10x110mm)	4	
4	Light Arm	1		9	Bolt (M6x25mm)	8	
5	Seat Cushion	2		10	Bolt (M6x45mm)	4	


Tools



STEP 1

PART REQUIRED: 2, 3 & 4


Keep the bolts loose.




STEP 2

PART REQUIRED: 1, 3 & 4


Keep the bolts loose.



Screw in half length of the bolt




Slide in the bolt to the die cut



STEP 3

PART REQUIRED: 1, 2, 3 & 4



Keep the bolts loose.



STEP 4

PART REQUIRED: 1, 2, 3 & 4


Keep the bolts loose.



STEP 5

PART REQUIRED: 3, 4 & 7


Keep the bolts loose.



STEP 6

PART REQUIRED: 5 & 6

Tighten all bolts. Finished!



Warranty

One-year limited warranty.

Proof of purchase (dated register receipt) is required for warranty claims.

It remains the customer's responsibility for freight and packing charges to and from the service center.