


BIG LOTS STORES, INC.

ASSEMBLY INSTRUCTIONS

★ Remark: Please be noted that the anti-tip wall mounted bracket set with instruction is attached at the back side of the back panel.



ITEM NO. : 1402DR

SKU NO. : 810223936

DESCRIPTION : MANOTICELLO DRESSER

BIG LOTS CUSTOMER CARE

For spare screws and bolts, please contact Big Lots Customer Care

Tel: 1-866-244-5687

E-Mail: talk2us@biglots.com

WARNING

Caution: Adult Assembly required. Assembly will require 2 people.
Assemble on soft surfaces to prevent damage to the product finish.
DO NOT use power tools.

CARE AND CLEANING

DO NOT scratch or chip the finish
DO NOT use abrasive chemicals for cleaning. Clean with mild soap on a soft rag.
Rinse and dry thoroughly.
DO NOT put hot objects over 80 degrees Fahrenheit directly on the surface .

MAINTENANCE

Check bolts/screws periodically and tighten if necessary.
WARNING: Should this product become damaged, and/or components are broken or missing, DO NOT USE.





ASSEMBLY INSTRUCTIONS

Item No. : 1402DR

SKU No. : 810223936

DESCRIPTION : MANOTICELLO DRESSER

WOOD PART LIST

	Dresser Top x 1 pc
	Front Leg x 2 pcs
	Back Leg x 2 pcs
	Center Leg x 1 pc

HARDWARE LIST

①		Thread Bolts ϕ 1/4" x 45mm	8 pcs
②		Lock Washer ϕ 1/4"	8 pcs
③		Flat Washer ϕ 1/4"x ϕ 19mmx2mm	8 pcs
④		Allen Key (D4mm)	1 pc

STEPS

1. Carefully lay your case on its back.
2. Attach Front Leg (B) and Back Leg(C) to the bottom of the case by Thread Bolt(1), Lock Washer(2), and Flat Washer (3) using Allen Key(4). Tighten all Bolts completely. Repeat until all legs are attached. (see DETAIL A)
3. Attach the Center Leg (D) to the bottom of the case by hand screwing it into the hole. (see DETAIL B)

