


South Bay Hexagon Easy Up Gazebo-Netting

Assembly Instruction

Item no# L-GZ793PST-A-MN



Warning

Keep all flame and heat sources away from this tent fabric. This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

Important

Please do not return this product to the store. For technical assistance or replacement parts, please call Sunjoy Group at 1 (866) 578-6569 between 8:00 AM EST and 8:00 PM PST. You may fax your replacement parts form (which is included in the packaging) to 1 (740) 283-3549 or email to customer.care@sunjoygroup.com

Parts List

Mosquito netting	L	1 pc	
------------------	---	------	---

Hardware

Plastic ring	BB	48 pcs	
--------------	----	--------	---

Remove the netting




Fig.1: Loosen the tieback on the post and the buckle on the netting.




Fig.2: Take down the netting (L) from netting pipe (M).




Fig.3: Take down the plastic ring (BB) from the netting.





Fig.1: Fix the plastic ring (BB) to the new netting (L).




Fig.2: Hang the netting (L) to the netting pipe (M) by the plastic ring (BB).





Fig.3: Draw the netting in by the buckle and elastic string and fix the netting to the post by tieback.



IMPORTANT

Please do not return this product to the store. For technical assistance or replacement parts, please call Sunjoy Group at 1 (866) 578-6569 between 8:00 AM EST and 8:00 PM PST. You may fax your replacement parts form (which is included in the packaging) to 1 (740) 283-3549 or email to customer.care@sunjoygroup.com. Attention! Please don't return the products to Big Lots store!

CARE AND MAINTENANCE

Do not use bleach, acid or other abrasive cleaners.

LIMITED WARRANTY

- This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided. The item is maintained with care and used only for personal, residential purposes.
- The item is warranted to be free from defects in material or workmanship for a period of one (1) year. If any defect is found, please call our customer service department at 1-866-578-6569 for help. The manufacturer will not cover transportation or delivery costs, **nor** compensate the individual or any outside party for assembling or disassembling the product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

EXCLUSIONS

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.