

Domed Top Grill Gazebo-Canopy

Assembly Instruction

Item no# L-GG035PST-PK



SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble or install the product.

WARNING

Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area.

Keep all flame and heat sources away from the tent fabric. This tent is made with fabric that meets CPAI-84 specification for flame resistance. It is not fireproof. The fabric will burn if left in continuous contact with any flame sources. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.

Parts List

Small canopy	J	1 pc	
Big canopy	K	1 pc	

Remove the canopy




Fig.1: Take the big canopy (K) from four corners of cant beam (G) and take it away.




Fig.2: Take the small canopy (J) from four corners of cant beam (G) and take the small canopy (J) down from the top.





Fig.3: Take down the big canopy (K) from the top.



Replace the canopy




Fig.1: Put the big canopy (K) onto the big top but do not spread put.




Fig.2: Put the small canopy (J) on the small top and fix the small canopy to the four corners of cant beam (G).





Fig.3: Spread out the big canopy (K) on the big top and fix four corners of big canopy (K) to the bottom of cant beam (G).



IMPORTANT: Please do not return this product to the store. For technical assistance or replacement parts, please call Sunjoy Group at 1 (866) 578-6569 between 8:00 AM EST and 8:00 PM PST. You may fax your replacement parts form (which is included in the packaging) to 1 (740) 283-3549 or email to customer.care@sunjoygroup.com

CARE AND MAINTENANCE

Do not use bleach acid, or other abrasive cleaners.

LIMITED WARRANTY:

This limited warranty is extended to the original purchaser and applies to defects in material and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes.

The item is warranted to be free from defects in material or workmanship for a period of one (1) year. We don't reimburse for transportation or delivery costs, or compensate the individual or any outside party for assembling or disassembling the product.

EXCLUSIONS:

Items used for commercial, contract, or other non-residential purposes, or items damaged due to acts of nature, vandalism, misuse, or improper assembly are not covered. Corrosion or rusting of hardware is not covered. Proof of purchase (dated register receipt) is required for warranty claims. Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color, or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.