


Assembly Instructions

L-BB050PCO-1













Parts list

Number	Description	Qty
A	Big bird	1
B	Little bird	2
C	Pot	1
D	Connector	1
E	Crane	3
F	Leg 1	3
G	Leg 2	3
H	Bottom base	1



Hardware list

Number	Description	Qty	Image	Number	Description	Qty	Image
AA	Stud M6*35	6		FF	Nut M6	12	
BB	Bolt M6*35	6		GG	Flat washer M6	15	
CC	Bolt M6*20	3		HH	Stud M8*30	3	
DD	Bolt M6*15	3		II	Nut M8	3	
EE	Wrench M6/M8	1		JJ	Flat washer M8	3	




Fig.1: Put leg 2 (G) at the inner side of the crane, then connect with bolt (BB), flat washer (GG) and nut (FF); connect leg 1 (F) in the same way.

Fig.2: Insert the end of bolt (AA) without the "-" symbols into the holes leg 1 (F)/ leg 2 (G), and lock and tighten with a screwdriver.

Fig.3: Connect leg 1 (F)/ leg 2 (G) and bottom base (H) with bolt (AA), flat washer (GG) and nut (FF).

Fig.4: Connect connector (D) and crane (E) with bolt (CC).

Fig.5: Insert the end of bolt (HH) without the "-" symbols into the holes of pot (C), and lock and tighten with a screwdriver.

Fig.6: Attach connector (D) to pot (C) with bolt (HH), flat washer (JJ) and nut (II).

Fig.7: Connect big bird (A) to pot (C) with bolt (DD) and flat washer (GG).

Fig.8: Connect little bird (B) to pot (C) with bolt (DD) and flat washer (GG).

Fig.9: Tighten all the bolts with wrench (EE) and self-prepared screwdriver.

CARE AND MAINTENANCE:

To extend the life of garden cart, cover it in bad weather. Due to natural properties of steel material, if rust develops, please clean rust area by sanding slightly, then wipe thoroughly and apply touch-up paint if possible.

Limited Warranty:

This limited warranty is extended to the original purchaser and applies to defects in materials and workmanship of your item provided the item is maintained with care and used only for personal, residential purposes.

The item is warranted to be free from defects in material or workmanship for a period of **6 months**. If any defect is found, please call our customer service department at 1-866-578-6569 for help. The manufacturer will not cover transportation or delivery costs, or compensate the individual or any outside party for assembling or disassembling the product. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Service:

For technical assistance on assembly or replacement parts, please call SunNest Services at 1(866)578-6569 from 8:30 AM to 5:30 PM EST or send email to customer.care@sunjoydirect.com or visit www.sunjoyonline.com to place your order or fax your parts replacement order form together with your purchase receipt to 1 (740) 283-3549 for assistance.