



ASSEMBLY INSTRUCTIONS

ITEM# : GBO22-602-1

SKU# : 810544469

ASHEVILLE SECTIONAL SET RIGHT ARM SOFA AND LEFT ARM SOFA

Need help? We are here for you! 1-888-733-8169 Toll Free

Or email us at customerservice_01@yeah.net, customerservice_02@yeah.net

customerservice_03@yeah.net

GENERAL BEST PRACTICE FOR ASSEMBLY:

Read all instructions before starting

Clear a flat covered space to begin assembly

Always best to do it with a friend

Note that hardware required is provided for every step

Pay attention to orientation

Letter of the part corresponds to a sticker on the product

Number of the hardware corresponds to its letter in the package

Helpful hints provided along the way

Retain these assembly instructions for future reference.

WARNINGS:

Use the correct bolts as indicated. All bolts should be hand tightened until the complete piece is assembled (This will make the assembly process much easier). Once the piece is fully assembled, then go back and tighten all bolts with provided tool.

Regularly check hardware and tighten if necessary.

Use the correct bolts as indicated. **Do not tighten any of the bolts until the sofa is completely assembled.**

Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.

Keep children and pets away during assembly. This item contains small parts that can be swallowed by children.

Children should always be under direct adult supervision while using this product.

Sofa is for sitting purposes only. Standing on or misuse of sofa may result in damage or injury.

Weight limit is 500 lbs (226.79 kg). Not intended for commercial use.

MAINTENANCE:

Wash frame and fabric parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or fabric parts.

The cushions may be washed on the surface only by using mild soap and water or a commercial foaming upholstery cleaner if necessary.

If washed, rinse well and hang to dry. Do not machine wash or dry.















We recommend the use of furniture covers when not in use.



Inspect and tighten all of the bolts and fasteners on a regular basis to ensure the proper performance and safety of your sofa.

In order to prolong the life and beauty of your sofa, we recommend that it be stored in a dry and protected area during off season periods.

PARTS LIST FOR


RIGHT ARM SOFA:

Part No.	Part	Qty	Image	Part No.	Part	Qty	Image
R1	Sofa Back	1		8	Short Bolt (M6x20mm)	8	
R2	Sofa Seat Panel	1		9	Middle Bolt (M6x36mm)	9	
R3	Armrest	1		10	Long Bolt (M6x44mm)	2	
R4	Back Armrest Foot (with one threaded hole)	1		11	Washer	18	
R5	Front Armrest Foot (with two threaded hole)	1		12	Back Cushion	2	
6	Back Foot	1		13	Seat Cushion	1	
7	Front Foot	1		16	U - shape Connection Lock	1	




Note: There are 1 pc PART 10 long bolt to match PART 16 U - shape connection lock. No washer is needed for this one.

PRODUCT FRAME MAP



STEP 1

PART REQUIRED: R3, R4 & R5
Keep the bolts loose.






Note: After assembled, keep all the threaded holes inwards.

STEP 2

PART REQUIRED: R1, R2, 6 & 7



Keep the bolts loose.



STEP 3



PART REQUIRED: R1 & R3

Keep the bolts loose.



STEP 4

PART REQUIRED: R2, R4 & R5
Keep the bolts loose.



STEP 5















PART REQUIRED: 12 & 13
Make sure the sofa stand on the ground stable, then tighten all the bolts.
Put the cushions on the seat.





Warranty
One-year limited warranty.
Proof of purchase (dated register receipt) is required for warranty claims.
It remains the customer's responsibility for freight and packing charges to and from the service center.

PARTS LIST FOR


LEFT ARM SOFA:

Part No.	Part	Qty	Image	Part No.	Part	Qty	Image
L1	Sofa Back	1		8	Short Bolt (M6x20mm)	8	
L2	Sofa Seat Panel	1		9	Middle Bolt (M6x36mm)	9	
L3	Armrest	1		10	Long Bolt (M6x44mm)	2	
L4	Back Armrest Foot (with one threaded hole)	1		11	Washer	18	
L5	Front Armrest Foot (with two threaded hole)	1		12	Back Cushion	2	
6	Back Foot	1		13	Seat Cushion	1	
7	Front Foot	1		16	U - shape Connection Lock	1	




Note: There are 1 pc PART 10 long bolt to match PART 16 U - shape connection lock. No washer is needed for this one.

PRODUCT FRAME MAP



STEP 1


PART REQUIRED: L3, L4 & L5
Keep the bolts loose.



Note: After assembled, keep all the threaded holes inwards.



STEP 2

PART REQUIRED: L1, L2, 6 & 7
Keep the bolts loose.





STEP 3

PART REQUIRED: L1, & L3
Keep the bolts loose.



STEP 4

PART REQUIRED: L2, L4 & L5
Keep the bolts loose.



STEP 5

PART REQUIRED: 12 & 13
Make sure the sofa stand on the ground stable, then tighten all the bolts.
Put the cushions on the seat.






REMINDER

REQUIRED: Sectional Set CTN#1 - Right Arm Sofa and Left Arm Sofa and CTN# 2 - Corner Sofa

Two other connection locks is included in the hardware pack for sectional sofa set CTN#2 - Corner Sofa .

PLEASE FIX SOFA SEAT TOGETHER WITH PROVIDED



Warranty

One-year limited warranty.

Proof of purchase (dated register receipt) is required for warranty claims.

It remains the customer's responsibility for freight and packing charges to and from the service center.