



GREENHOUSE WITH THREE VENTILATION WINDOWS

ASSEMBLY INSTRUCTIONS

ITEM# GB-M1607

SKU# 810555285

DO NOT RETURN THIS PRODUCT TO THE STORE. FOR MISSING PARTS OR QUESTIONS TO THIS PRODUCT PLEASE CALL US AT 1-888-733-8169
OR EMAIL US AT customerservice_01@yeah.net OR customerservice_02@yeah.net OR customerservice_03@yeah.net

IMPORTANT:

Ensure you read and fully understand instructions before use.

While every attempt is made to ensure the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury due to use. All merchandise is sold on this condition, which no representative of the company can waive or change.

WARNING:

Make sure all fastenings are tightly in place and that everything is in order before using the product. This should be checked periodically by an adult.

This product is intended for outdoor use only. It is strongly recommended to store the product during heavy weather conditions of strong wind or rain as both can cause damage of product.

This product is designed and intended for commercial and recreational usage. Prolonged exposure to UV rays will cause any fabric to fade and deteriorate and is NOT covered by this 1 Year Limited Warranty.

Never set up or continue to use in any rain, wind or storm conditions, especially lightning storms. Damage can occur to your canopy and put you and others in potential danger.

We suggest that you take your time in order to avoid bending the frame or pinching your fingers or hands while opening and closing the frame.

Select ideal location. Set out all parts on a clear and leveled surface prior to assembly. Avoid setting up your canopy on steep inclines.

Do not use your canopy for permanent shelter. It is designed for temporary use only.

Keep your canopy away from heat and flames at all times. Do not barbecue or build fires under your canopy.

Never leave your canopy unattended.

CARE & MAINTENANCE










Hand wash the canopy using only mild soap and water. Never use harsh detergents, abrasives or bleach. Do not machine wash fabric components.

Never fold or store your canopy when it is wet or damp. Let it dry completely to avoid mildew.

The frame MUST be staked or properly weighted down at all times.

For best results in keeping your top clean and avoid small rips and tears, it is recommended that the top be removed from the frame and stored in the carry bag after each use.

PARTS LIST

| NO. | Part | Qty | Image | NO. | Part | Qty | Image |
|-----|------------------|-----|---|-----|-----------------------|-----|---|
| 1 | Short Pole | 15 |  | B | Middle Bottom Bracket | 8 |  |
| 2 | Corner Pole | 8 |  | C | Middle Side Bracket | 4 |  |
| 3 | Middle Long Pole | 8 |  | D | Middle Top Bracket | 2 |  |
| 4 | Long Pole | 2 |  | E | Cover | 1 |  |
| A | Corner Bracket | 6 |  | | | | |


Warranty

One-year limited warranty.

Proof of purchase (dated register receipt) is required for warranty claims.

It remains the customer's responsibility for freight and packing charges to and from the service center.

SET UP THE GREENHOUSE



Once assembled, slide the Cover (E) over the frame and secure with ties in the bottom corners.