

Lit Wagon









Operating and Safety Instructions



- FOR INDOOR AND OUTDOOR USE -




PARTS:


Part	Description	Illustration	Qty
A	Wagon body		1
B	Wagon bar		1
C	Wheel		2
D	Handle		1
E	Candy cane		2
F	Gift box		2
G	Plastic Ties		8
H	Ground Stake		4

TO Assemble


1. Remove all of the parts from the box carefully and lay out the components.
2. Insert the metal hooks of the Wheels (C) and the Wagon bar (B) into the corresponding rings on the Wagon body (A).




3. Insert the metal hooks of the Handle (D) into the corresponding rings on the Wagon body (A).



4. Insert the prong of the Candy cane (E) into the corresponding rings on the Wagon body (A).



5. Insert the prongs of the Gift boxes (F) into the corresponding rings of the Wagon bar (B)



6. Secure the installing points with plastic ties and secure the base to the soft ground by fully inserting 4 stakes into the ground.

To Use

1. To illuminate, plug the power cords into a standard 120-volt AC electrical outlet.
2. To shut off, unplug the power cord from the outlet.

WARNING: To reduce the risk of fire or electric shock, if one or more bulbs do not illuminate, replace the bulb(s) according to the "User Servicing Instructions" section of the included "Important Safety Instructions" sheet.

Distributed By:
Big Lots Stores, Inc.
PO Box 28523
Columbus, OH 43228-0523